



# Toshiba Portege R835-P88 RAM Replacement

Replace the RAM in your Toshiba Portege R835-P88.

Written By: Colby



## INTRODUCTION

Use this guide to replace the RAM in your Toshiba Portege R835-P88.

---



### TOOLS:

- [Small Phillips Head Screwdriver](#) (1)
-

## Step 1 — RAM




- Remove the battery by sliding the interlocks to the unlock position.

## Step 2



- Remove the two 6mm screws from the RAM cover. Lift the RAM cover upward to remove.

## Step 3



- Push back the little white plastic clips to extract the RAM.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-14 04:36:35 PM.